
OPERATION MANUAL

DATE OF MONTH - SWEEP SECOND

SETTING INSTRUCTIONS

If your watch is equipped with a locked crown make sure to read and follow the LOCKED CROWN instructions carefully.



Crown position I → Normal function

Crown position II → Date setting (quick mode)

- An extreme acceleration in setting the date with quick mode can induce a false date indication. The synchronisation is re-established by setting the date from 01 till 31 (crown position II)

Crown position III → Time setting

- Watch stops. Energy saving mode (saving approx. 70%).

A. SETTING OF TIME

- Pull crown to position Nr. III, turn crown forward (clockwise) – never backwards - to adjust minutes and hours. Push crown back to position Nr. I.

To synchronize the seconds with exact time standards, let the sweep second hand reach the 12 o'clock marker before pulling crown to position Nr. III. (The watch stops running the instant crown is in position Nr. III.) After setting the time as instructed in A., at the precise moment of a time signal, push crown back to position Nr. I.

B. SETTING DATE OF MONTH:

- Pull crown to position Nr. II (This will not affect the time). Turn crown forward to desired date of month. Push crown back to position Nr. I.

Note: The date will automatically change at midnight if watch is in proper AM-PM Cycle. Should the date change at noon instead of midnight, advance hands by a full 12 hours and then set the date again (if necessary) as instructed in B.

IMPORTANT: - LOCK THE CROWN!!! – if your watch is equipped with such a feature.